



# OWNER'S MANUAL

Item: L-GZ120PST-9D



**Recommended persons for safe assembly:**

Our clear, easy to follow; step by step instructions will guide you through the project from start to finish. Feel confident that this will be a fun and rewarding project. The assembled product will be a quality piece that will go together smoothly and give years of enjoyment.

All you will need is a screwdriver, a hammer, and a ladder not lower than 2m (about 6.6 feet).

















**IMPORTANT:**

1. When installing and assembling your gazebo, it's recommended that 2 or more persons are involved.
2. Do not use the unit during an electrical storm, as there is a remote chance of getting struck by lightning.
3. Do not climb on top of the gazebo. Falling off the gazebo can result in serious injury, possibly even death.
4. Do not leave the gazebo assembled when there is a risk of high wind, as damage will occur to the structure.
5. Never barbecue under this gazebo or use lanterns that contain naked flames.
6. This package contains small items and plastic bags that should be kept away from children.
7. Ensure that any connectors & poles are firmly secured in position fully. It is important to do so before use so as to avoid collapsing or damage to the item, which could result in injury.

**WARNING:**

1. KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS GAZEBO FABRIC.
2. This Gazebo is made of Fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.


## Parts List

Big screen	A1	4	
Left screen	B1	4	
Right screen	C1	4	
Long Bar	A2	2	
Short Bar	A5	2	
Larger Roof Connector	A3	1	
Top Roof Supporter	B3	4	
Arch bar 1	C3	4	
Arch bar 2	C4	4	
Arch bar connector	C5	8	
Side Supporting Bar-Short	D2	2	
Side Supporting Bar-Long	D3	2	
Center Hook	F3	1	
Larger Canopy	G3	1	
Top Canopy	H3	1	
Mosquito Netting	I3	1	

### Hardware Pack 1

16pieces

(AA) M6x20 Bolt




16pieces

(CC) M6 Flat washer



1 piece

(W2) M6 Wrench



Insert the left screen (B1) into the big screen (A1), pull it down to fix them, then use screw (AA), washer (CC) to secure left screen (B1) and big screen (A1). Do the same for right screen (C1) and big screen (A1).

### Hardware Pack 2

16pieces


(BB) M6x15




16pieces

(CC) M6 washer





Connect long bar (A2) and left screen (B1), long bar (A2) and right screen (C1) by bolt (BB) and washer (CC). Connect short bar (A5) and left screen (B1), short bar (A5) and right screen (C1) in the same way.




### Hardware Pack 3


24pieces (CC) M6 Flat washer





4pieces (FF) M6x30 Bolt




16pieces (HH) M6x15 Bolt






4 pieces (GG) M6 Nut



Attach center hook (F3) to larger roof connector (A3).





Insert top roof supporter (B3) into larger roof connector (A3).





Insert arch bar 1(C3) and arch bar 2 (C4) into top roof supporter (B3).


Insert arch bar 1(C3) and arch bar 2 (C4) into Arch bar connector (C5), fully tighten by bolt (HH) and flat washer (CC).




Insert arch bar connector (C5) into big screen (A1).





Insert side supporting bar-Short (D2) and side supporting bar-Long (D3) into larger roof connector (A3).




Connect Side Supporting Bar (D3&D2) and bar (A2&A5) by bolt (FF), washer (CC) and nut (GG).



Put Larger Canopy (G3) on to the top frame. Don't unfold it completely at this time.





#### Hardware Pack 4



8pieces

DD Dia.6x180 stake




56pieces

EE plastic ring



Attach Mosquito netting (A4) onto bar (A2, A5) by plastic ring (EE).



Fix the completely assembled gazebo by stake (DD).



## **Limited Warranty:**

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes.

The item is warranted to be free from defects in material or workmanship for a period of **one (1) year**. We don't reimburse for transportation or delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

## **Exclusions:**

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

## **Maintenance:**

Our iron/steel components for garden accessories and furniture are coated with rust inhibiting paint that protects it from rusting. However, due to the nature of iron, surface oxidation (rusting) will occur once these protective coatings are scratched. This is a natural process and is not a defect! To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, we recommend immediate touch-up with rust inhibiting paint. Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and cause damaging stains, which may be difficult to remove. This can be prevented if measure is taken to keep the product from oxidizing.

**Important: Please do not return this product to the store.** For technical assistance on assembly or replacement parts Please do not return this product to the store, call Sunjoy Industries at 1(866) 578-6569 from 8:30 AM to 5:30 PM EST Monday to Friday or fax the replacement part form which put into the package to (740)-283-3549 or Email [customer.care@sunjoydirect.com](mailto:customer.care@sunjoydirect.com) for assistance.

Made in China